

Ford Motor Company
Customer Relationship Center
U.S. » 1-800-392-3673 (FORD)
(TDD for the hearing impaired:
1-800-232-5952)

fordowner.com

Ford of Canada's
Customer Relationship Centre
Canada » 1-800-565-3673 (FORD)
ford.ca



This Quick Reference Guide is not intended to replace your vehicle Owner's Manual which contains more detailed information as well as important features of your vehicle designed to help reduce the risk of injury to you and your passengers. Please read your entire Owner's Manual carefully as you begin learning about your new vehicle and refer to the appropriate chapters when questions arise. All information contained in this Quick Reference Guide was accurate at the time of publication. We reserve the right to change features, operation and/or functionality of any Ford vehicle at any time. Your Ford dealer is the best source for the most current information. For detailed operating and safety information, please consult your Owner's Manual.

learn more about
your new C-MAX

To put QR tags to work for you, use your mobile phone's browser or app store link to download a QR tag reader. Then follow the directions to scan the QR tag and see your vehicle's features come to life.

WARNING

Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.



DM5J 19G217 LA
June 2013
Third Printing
Quick Reference Guide
C-MAX Hybrid
Litho in U.S.A.
FSC® C102270





fuel tips

FUEL HISTORY AND COACH

Within the information displays, you'll be able to see how your driving style directly impacts your fuel economy.

The instant fuel economy gauge provides instant fuel economy, plus your recent fuel economy averaged over selectable intervals of 1, 2 or 6 minutes.

The fuel coach gauge can teach you how to improve your fuel economy by providing feedback on your recent Acceleration, Braking and Cruising behavior.

ECO Cruise Control* saves vehicle energy by slowing down acceleration compared to standard cruise control. Your vehicle may relax its acceleration temporarily when going uphill. This feature can be turned on and off through the Driver Assist section of the Settings menu in the information display.

MAXIMIZE YOUR FUEL ECONOMY

Get the Best Fuel Economy When You Utilize These Few Tips

- 1. Use smooth acceleration and braking.** According to the United States Department of Energy, aggressive driving can lower your gas mileage by up to 33 percent at highway speeds and 5 percent in the city.
- 2. Carry the bare essentials.** The Department of Energy estimates that an extra 100 pounds in your vehicle could reduce your fuel economy by up to two percent.
- 3. Seasonal fuel makes a difference.** Winter fuel contains slightly less energy than summer fuel, so the fuel blend you fill up with can impact your efficiency.
- 4. Idling burns fuel, too.** You can burn up to half a gallon (1.9 liters) of fuel per hour while idling. Minimize your morning warm-up and parking lot waits to get the most out of filling your tank.
- 5. Avoid extreme temperatures.** Find a shady or sheltered spot to help keep your lithium-ion battery operating efficiently, and minimize the amount of energy required to heat or cool your cabin temperature.
- 6. Use fewer accessories.** Heated seats, the rear defroster, the air conditioner and other power features draw electrical energy. When you operate your accessories, you may notice that the gasoline engine needs to start. Check out your "Accessory Power" screen in your SmartGauge to see how much electricity is being used to power your vehicle's accessories.
- 7. Check your tires.** Proper tire inflation helps you improve your fuel economy by up to 3.3 percent, according to the Department of Energy, while underinflation could lower your fuel economy by 0.3 percent for every 1 psi drop in pressure of all four tires. Check your vehicle's door sticker for recommended cold tire inflation pressure.

*if equipped



| | |
|---------------------------------------|-------|
| quick tips | 4 |
| hybrid features | 5 |
| instrument panel | 6–7 |
| getting started with your SYNC system | 8–9 |
| commonly used voice commands | 10 |
| SYNC with MyFord Touch | 11–13 |
| function | 14 |
| convenience | 15 |
| comfort | 16–17 |
| parking aids | 18 |
| essential information | 19 |



quick tips

The *Brake Coach* appears in the display after the vehicle has come to a stop, and coaches you to maximize the amount of energy that can be returned through the regenerative braking system.



SMARTGAUGE® WITH ECOGUIDE

Delivers specific information about various systems on your vehicle using menus that build on previous data. Use your left-hand, 5-way steering controls to scroll through your menu choices:

Vehicle Range: Estimates the distance your vehicle will travel on the fuel remaining in the tank. Changes in your driving pattern may cause the value to vary.

Inform: Provides average fuel economy, fuel levels and battery status.

Enlighten: Adds power demand and instant fuel economy.

Engage: Adds gas/electric power-split information.

Empower: Adds an engine on/off threshold to the power demand gauge from Enlighten. See how much power you request based on how far you press the accelerator pedal.

MyView: Lets you customize your menu options, allowing you to select key information into one, combined screen.

EcoGuide: Displays leaf graphics within the right-hand cluster, showing you when you're driving efficiently. More leaves equals better driving habits!



hybrid features

SILENT KEY START (SKS)

When you turn the ignition on, your engine may not sound like it has started because your hybrid-electric vehicle is equipped with silent key start. This fuel-saving feature allows your vehicle to be ready to drive without requiring your gas engine to be running. Instead of listening for a traditional gasoline-powered engine sound, look for the 'ready to drive' indicator light  in your instrument cluster. When the light illuminates, your vehicle has been successfully started and is ready to drive.

SMART POWER-SPLIT ARCHITECTURE


City Driving: In stop and go driving and at low speeds, the electric motor provides the necessary power. The gas engine kicks in only to recharge the battery or when more power is needed.

Accelerating: Step on the accelerator pedal and get all the responsiveness of a traditional gasoline engine.

Cruising/Highway Driving: Due to greater power demands at highway speeds, your vehicle will use the gasoline engine more frequently than it will while driving at city traffic speeds. This is normal.

Braking: For added efficiency, the energy created by friction during braking is recycled to the battery.

Stopped: To save energy, the gasoline engine will shut off and the electric motor will stop drawing current.



instrument panel

1 CRUISE CONTROL

To Set a Cruise Control Speed

1. Press the **ON** button and release.
2. Accelerate to the desired speed.
3. Press the **SET +** and release, then take your foot off the accelerator.

After your speed has been set, you can press **SET +** or **SET -** to adjust cruise speed. To disable, press the **OFF** button, tap the brake pedal or pull the **CAN** control toward you.

2 LEFT VEHICLE INFO DISPLAY

Provides specific information about various systems on your vehicle. Use the left, 5-way controls to use SmartGauge®, customize views, and choose and confirm settings and messages. Refer to the *Information Displays* chapter of your *Owner's Manual* for more information.



3 RIGHT VEHICLE INFO DISPLAY

Access information about Entertainment, Phone, Navigation* or the **animated EcoGuide with efficiency leaves** by using the right, 5-way controls. Scroll through the menu, highlight selections and make adjustments. Press **OK** to confirm your choices.

4 STEERING WHEEL MEDIA CONTROLS

Volume: Press $\triangleleft +$ to increase or $\triangleleft -$ to decrease volume levels. Press $\blacktriangleleft \blacktriangleright$ to access the next/previous radio station, CD track or preset satellite radio channel*.

\mathfrak{f} Pull to access voice recognition.

\mathfrak{c} Press to access phone mode or to answer a call.

\mathfrak{t} Press to end a phone call.

OK Press to confirm your selection.

5 TILT/TELESCOPE STEERING COLUMN

Unlock the steering wheel by pulling the lever down. Adjust the steering wheel to your desired position. Push the lever up to lock the steering wheel in place.

6 PUSH-BUTTON SILENT START*

Allows you to go into "Ready to Drive" mode by pressing the **POWER START/STOP** button while fully pressing down on the brake pedal. A green \mathfrak{f} "Ready to Drive" indicator light will appear in the instrument cluster after you start the vehicle. This lets you know that the vehicle is on and ready for driving. Press the **POWER START/STOP** button again to turn the vehicle off.

NOTE Your intelligent access key must be inside the vehicle to put the vehicle in accessory mode or "Ready to Drive".

7 HAZARD CONTROL

8 DOOR LOCK INDICATOR LIGHT

Illuminates when all of the doors are locked, and will not light when a door remains open or unlocked. The central door locks can be found on both driver and front-passenger doors, or on a keyless remote*.

getting started with your SYNC® system

SYNC Is a Hands-free,
Voice Recognition System
Used for Entertainment,
Information and
Communication.
SYNC. SAY THE WORD.

Before You Get Started

1. Set up your owner account at SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada).

Register by following the on-screen instructions. After registering you can see which services you may be eligible for.

2. SYNC uses a wireless connection called  *Bluetooth*® to communicate with your phone. Turn *Bluetooth* mode on in your phone's menu options. This lets your phone find SYNC. If you need more details on setting up your phone with SYNC, visit SyncMyRide.com (U.S.) or SyncMyRide.ca (Canada), or your phone manufacturer's website.



PAIRING YOUR PHONE WITH SYNC

In order to use many of the features of SYNC, you must first pair and connect your phone with SYNC.

To Pair Your Phone for the First Time

1. Make sure that your vehicle is in **P** (Park) and both your ignition and radio are turned on.
2. Press the  button. When the display indicates no phone paired, press **OK**.
3. When **Find SYNC** appears in the display, press **OK**.
4. Put your phone into *Bluetooth* discovery mode. See your phone's manual, if necessary.
5. When prompted on your phone's display, enter the six-digit PIN provided by SYNC in the radio display.
6. The display indicates when the pairing is successful.

NOTE The System May Prompt You to

- » Set your phone as the *primary/favorite* (the primary phone will receive messages and voicemail).
- » Download your phone book (this is required to use the full set of voice commands).
- » Turn on 911 Assist®.

TIPS

- » Make sure you accept SYNC's request to access your phone.
- » To pair subsequent phones, please refer to **Pairing Subsequent Phones** in the **SYNC** chapter of your **Owner's Manual**.
- » If you are experiencing pairing problems, try performing a clean pairing by deleting your services from SYNC, deleting the SYNC connection from your phone, and then repeating the **Pairing Your Phone with SYNC** process.

WHY DO I NEED A SYNC OWNER ACCOUNT?

A SYNC owner account is required for Vehicle Health Report activation and the ability to view your reports online. You'll also be able to take advantage of all of SYNC's Services and personalization features, such as saving your Favorites and Points of Interest (POI). You'll receive the latest software updates that add new places, directions and information; and if you have questions, you'll get free customer support. Create your account by visiting the website or calling the toll-free number for more information. See the **Commonly Used Voice Commands** page of this guide for more details.

USING MY PHONE WITH SYNC

NOTE Enter your phone book contacts with both first and last names to increase SYNC's ability to select the correct contact. Remember to say the contact name exactly as it is listed in your phone book.

Making a Phone Call

Use SYNC to make a phone call to anyone in your phone book by pulling the voice control  and when prompted, give a voice command. For a list of voice commands, say "**What can I say?**".

For example, you could say "**Call Jake Smith at home**". SYNC repeats the command back to you and dials the number.

NOTE You can make phone calls by pulling the voice control  and when prompted, give the voice command "**Dial**", then verbally say the phone number.

Answering Incoming Calls

Whenever you have an incoming call, you will be able to see the name and number of the person calling in the display. Press the  button to answer an incoming call. You can hang up at any time by pressing and holding the  button.

Do Not Disturb Mode

This feature blocks incoming calls and text messages, and saves them for later. You still have access to outgoing calls when this feature is active. Say the voice command "**Do not disturb on**" to enable and "**Do not disturb off**" to disable.



USING SYNC TO ACCESS DIGITAL MEDIA

Plug in your USB media devices, such as phones and MP3 players, and use SYNC to play all of your favorite music.

Using Voice Commands to Play Music

1. Plug your media player into your USB port.
2. Pull the voice control  . When prompted, say "**USB**", then follow-up by saying one of the voice commands. For a list of voice commands, say "**What can I say?**".

commonly used voice commands

SYNC® SAY THE WORD.

Pull the  voice control on the steering wheel, and then say:

Basic Commands

- » What can I say?
- » List of commands
- » Main menu
- » Previous
- » Next
- » Go back
- » Exit
- » Help
- » Vehicle health report
- » Pair my phone

Phone

- » Phone list of commands
- » Dial
- » Call <name> on cell/ at home/at work
- » Call voicemail
- » Do not disturb
- » Listen to text message (phone-dependent feature)

Entertainment

- » Audio list of commands
 - You can also get detailed lists of commands for radio, USB, Bluetooth® audio, Sirius and SD card
- » Radio
 - FM <87.9-107.9>
 - FM preset <#>
- » CD
 - Play track <1-512>
 - Shuffle <On/Off>
- » USB
 - Play song <name>
 - Play album <name>
- » SiriusXM
 - <channel name>
- » Preset <#>

Navigation**

- » Navigation list of commands (if equipped)
 - Destination street address <number, name, city>
 - Destination home
 - Navigation voice <On/Off>
 - Navigation voice volume <increase/decrease>
 - Repeat instruction
 - Show <map/north-up/ heading-up/3D>
- » Travel Link list of commands
 - Traffic
 - Weather
 - Movie listings
 - Fuel prices
 - Sports <headlines/ scores/schedule>

**Available only with MyFord Touch



SYNC Services

If equipped, say "Services" first, and then "What can I say?"

- » Traffic
- » Directions
- » Business search
- » Operator (for direction or business search)
- » Favorites
- » News, sports, weather, horoscopes, stock quotes, movies or travel
- » Help

Climate

- » Climate control list of commands
- » Climate <On/Off>
- » Climate my temperature
- » Climate temperature <60-85> degrees

SYNC® with MyFord Touch®*

A REVOLUTIONARY WAY TO CONNECT WITH YOUR VEHICLE.



GETTING STARTED, UNDERSTANDING SYNC WITH MYFORD TOUCH

Use the four-corner, four-color touchscreen to explore and interact with your vehicle. The touchscreen works the same way as traditional controls, knobs and buttons do. Press the various corners on your touchscreen firmly and accurately to personalize the many features and settings of your vehicle. The system provides easy interaction with your cellular phone, multimedia entertainment, climate controls and navigation system.

Hybrid Screen Information

Press the "road and leaf" icon to access features specific to your hybrid vehicle.

- » The Power Settings display shows you where your vehicle power is coming from and where it is being used.



GENERAL TIPS

- » Press the home icon  at any time to return to your home screen.
- » For additional support, refer to your **Owner's Manual**, visit the website or call the toll-free number. See the **Commonly Used Voice Commands** page of this guide for more details.

Some services may not be available in your area. Refer to your **Owner's Manual**, visit the website or call the toll-free number for more information. **For U.S. customers:** visit SyncMyRide.com or call 1-800-392-3673 (select Option 1 or 2 for language, then Option 3). **For Canadian customers:** visit SyncMyRide.ca or call 1-800-565-3673 (select Option 1 or 2 for language, then Option 3).

SYNC® with MyFord Touch®* continued



PHONE

Voice-control your phone for hands-free calling with your phone securely put away. With SYNC, you won't even need to know the phone number. Just say the name of the person you want from your contacts.



Your Phone Connects You with Many Other Features and SYNC Services*

- » Connect to SYNC Services* for traffic, directions, business searches and information favorites.
- » Connect to Operator Assist to help locate a listing or destination.
- » Call for a Vehicle Health Report.
- » Connects directly to a 911 Operator in the event of an accident (feature must be set to ON prior to an incident).
- » Transfer calls seamlessly from SYNC to phone as you get in or out of your vehicle.

Refer to the **SYNC** chapter of your **Owner's Manual** for complete details.



NAVIGATION*

Get started with your navigation system by pressing the upper-right, green corner. The available voice-activated navigation system includes:

- » SiriusXM Traffic
- » SiriusXM Travel Link
- » GPS (Global Positioning System) technology
- » 3-D mapping
- » Turn-by-turn navigation

Refer to the **MyFord Touch** chapter of your **Owner's Manual** for complete details.



TIPS

- » Save your favorite locations by touching **Save to Favorites**.
- » Change your map views from Direction Headed, North Up or 3D.

Set a Destination

Set a destination on your touchscreen by using a street address, a city center, a place on the map or a Point of Interest (POI). The easiest way, however, is by voice.

1. Pull the voice control (1). When prompted, say "**Destination street address**".
2. The system will ask you to say the full address and will display an example on-screen.
3. You can then speak the address naturally, such as: "**One two three Main Street, Anytown**".

You can also use the touchscreen to enter a destination and narrow your choices by city or street as you type.

You can choose from up to three different types of routes:

- » **Fastest**: Uses the fastest moving roads possible.
- » **Shortest**: Uses the shortest distance possible.
- » **Eco (EcoRoute)**: Uses the most fuel-efficient route.

GET IN TOUCH USING YOUR FOUR-CORNER TOUCHSCREEN

Phone, Navigation, Climate and Entertainment are the four main features of SYNC with MyFord Touch. Each feature has its own corner represented by its own color.



CLIMATE

SYNC with MyFord Touch controls the temperature, airflow direction, fan speed, and activates other climate features for you and your passenger. To use voice commands to operate climate, say a voice command like "**Climate temperature 72 degrees**" and MyFord Touch will make that adjustment.



Set Your Temperature

- » Touch the lower-right, blue Climate corner on the touchscreen.
- » Set your exact, desired temperature by using the + or - buttons.



ENTERTAINMENT

No matter how you store your music, SYNC makes it yours to enjoy when you're behind the wheel. Just press the lower-left, red corner of the touchscreen. From here, you can easily go between AM/FM, Sirius and other media sources.



Set Your Radio Presets

- » Touch the Entertainment corner on the touchscreen.
- » Touch **FM**.
- » Touch **Direct Tune**.
- » Enter the desired station and touch **Enter**.
- » Touch **Presets** and then touch and hold one of the memory preset buttons to save it. The sound will mute briefly and return once the station is saved.

- » **USB**
- » **Bluetooth® Streaming**
- » **SD Card**
- » **A/V In**

Refer to the **MyFord Touch** chapter in your **Owner's Manual**, visit the website or call the toll-free number for more information. See the **Commonly Used Voice Commands** page of this guide for more details.

Bring in Your Own Music

Gain access to any audio source by voice and even control how each operates, like changing radio stations, CD tracks or music on one of the following devices:



function

INTELLIGENT ACCESS*

NOTE Your intelligent access key must be within 3 feet (1 meter) of the vehicle for intelligent access to function properly.

To unlock the driver's door: Pull the front exterior door handle. Touch the raised sensor on the driver's door handle to lock your vehicle.

To unlock and open the liftgate: Press the exterior liftgate release button near the license plate. The intelligent access key also contains a mechanical key blade, which can be used to unlock the driver's door if necessary. For complete information, refer to the *Keys and Remote Control* chapter in your *Owner's Manual*.



REMOTE START

To Remote Start Your Vehicle

1. Press the lock button to lock all the doors.
2. Press the remote start button twice. The exterior lamps will flash twice.

NOTE If you remote start your vehicle with an integrated keyhead transmitter, you must switch the ignition on before driving your vehicle. If you remote start your vehicle with an intelligent access transmitter, you must press the **START/STOP** button on the instrument panel once while applying the brake pedal before driving your vehicle. For complete information, refer to the *Remote Control* chapter in your *Owner's Manual*.

MYKEY®

MyKey allows you to program certain driving restrictions in order to promote good driving habits. You can program things like: speed restrictions, limited volume levels and safety belt reminders. For complete information, refer to the *MyKey* chapter in your *Owner's Manual*.

110-VOLT AC POWER POINT*

The power point is located on the rear of the center console and can be used to power your smaller electrical devices that do not exceed 150 watts. This feature is available to use when your ignition is turned on and the battery voltage is above 11 volts. When the indicator light is on, the power point is working and ready to use.



CARGO STORAGE

Your vehicle is equipped with two under-floor storage compartments that are located behind the front seats. You can use these compartments to store smaller items discretely. With the lids secured, your items will stay in place while you drive.



convenience

MANUAL LIFTGATE

To open the liftgate manually from outside of your vehicle, press the button located in the top of the liftgate pull cup handle to unlatch the liftgate, and then pull on the outside handle.

You can also use the remote control to open your liftgate. Press the  button twice within three seconds.

Use the molded handle inside the liftgate to help with closing.

POWER LIFTGATE*

You can open the power liftgate from the instrument panel by pressing the  button, or with the remote control by pressing the  button.

If the vehicle is running, the liftgate will only operate with the transmission in **P** (Park). Three warning tones will sound once as the liftgate begins to power close.



Five short tones indicate a problem with the open or close request, caused when:

- » the ignition is on and the transmission is not in **P** (Park)
- » the battery voltage is below the minimum operating voltage
- » or the vehicle speed is at or above 3 mph (5 km/h).

HANDS-FREE POWER LIFTGATE*

Open Your Liftgate Hands-free While You Are at the Liftgate

Move your leg toward and under, then away from the rear bumper (similar to a kicking motion). The liftgate will power open or close.

NOTE Your intelligent access key must be within 3 feet (1 meter) of the liftgate for the "hands-free" open feature to work. The liftgate will not power open or close under specific conditions. Refer to the *Locks* chapter in your *Owner's Manual* for more information.



SETTING THE LIFTGATE OPEN HEIGHT*

To Change Your Liftgate Opening Height

1. Open the liftgate.
2. Manually move the liftgate to the desired height.
3. Press and hold the control button on the liftgate until you hear a tone, indicating the new height has been programmed. The new open liftgate height will now be recalled when the power liftgate is opened.
4. To change the programmed height, repeat the above procedure. Once the power liftgate is opened, it can be manually moved to a different height.

*if equipped

comfort



DUAL CLIMATE CONTROLS

With the dual climate controls, you have the flexibility to operate the temperature with one control, called mono mode, or two, where both driver and front passenger can select independent temperatures using their own rotary dials.

To operate the dual temperature control: Use the rotary control on the passenger's side. Mono mode automatically shuts off.

To return back to mono mode: Press and hold the **AUTO** button. The passenger's side temperature automatically adjusts to the driver's side temperature setting, and both sides will then remain linked to the driver's control.



FOLDING THE REAR SEATBACK

To Fold the Rear Seat Back

1. Fold the outboard head restraints and lower the center head restraint.
2. Pull the lever up to fold the seatback forward.
3. To unfold the seatback, simply pull up on the seatback to raise it to the upright position.

PANEL ROOF WITH SUNSHADE*

The sun shade controls are located on the overhead console. The sun shade has a one-touch open and close feature. To stop motion during one-touch operation, press the control a second time.

Opening and Closing the Sun Shade

Fully press and release the front of the control to open the sun shade. Fully press and release the rear of the control to close the sun shade. For more complete information, see the **Windows and Mirrors** chapter of your **Owner's Manual**.



*if equipped

TIKLING FRONT-ROW HEAD RESTRAINTS*

The front head restraints may have a tilting feature for extra comfort.

To Tilt the Head Restraint, Do the Following

1. Adjust the seatback to an upright driving or riding position.
2. Pivot the head restraint forward toward your head to the desired position. After the head restraint reaches the forward-most position, pivot it forward again to release it to the rearward, un-tilted position.



INTERIOR LAMPS

The lamps will switch on when you open any door, press a remote control button or press  on the overhead control.

Press  to disable the interior lamps when you open any door. The door function indicator "lamp will illuminate yellow.

Press  again to turn the interior lamps back on. The indicator lamp will illuminate blue.

Press  to switch all lamps on and off.



AMBIENT LIGHTING*

Illuminate the interior with a choice of several colors by using the ambient lighting feature. The ambient lighting controls are located in the overhead console.

Color Palette: Press to cycle through the various color choices.

Control Knob: Turn the knob past the first detent to switch ambient lighting on and adjust the brightness.

Search Mode: Press to switch on all interior lamps and ambient lighting. Press again to turn the interior lamps off.

The ambient lighting switches on when you switch the ignition and the headlamps on.

The ambient lighting will remain on until you switch the ignition off and either lock your vehicle, or allow the accessory delay timer to expire.



parking aids

ACTIVE PARK ASSIST*

Can detect an available parallel parking space and automatically steer the vehicle into that space (hands-free) while you control the accelerator, gearshift and brakes. The system visually and audibly instructs you to park the vehicle.


- » To start active park assist, press the button  located in the instrument panel below the audio system.
- » To stop the parking procedure, grab the steering wheel or press the control again. For complete information, refer to the *Parking Aids* chapter of your *Owner's Manual*.

NOTE Visibility aids do not replace the need to watch where the vehicle is moving.
Refer to your *Owner's Manual* for safety information, more details and limitations.



REAR VIEW CAMERA*

Provides a video image of the area behind the vehicle. The display automatically appears in the touchscreen when the vehicle is in **R** (Reverse) and uses colored guides to alert you of your proximity to objects.



*if equipped

EASY FUEL® SYSTEM

With this system, you simply open the fuel door, insert the nozzle and begin fueling. It is self-sealing and therefore protected against dust, dirt, water, snow and ice. Wait 10 seconds from the time the refueling nozzle is shut-off until you remove the nozzle from the vehicle to allow residual fuel in the nozzle to drain into the tank.

NOTE When refilling with a portable container, only use the funnel that comes with your vehicle. Do not use aftermarket funnels as they will not work with the Easy Fuel system and may cause damage. Extra funnels can be purchased from your authorized dealer.



essential information

TIRE MOBILITY KIT

C-MAX Hybrid is equipped with a tire mobility kit that is located under the front passenger seat. It consists of an air compressor to reinflate the tire and a sealing compound in a canister that will seal most punctures caused by nails or similar objects. See the *Wheels and Tires* section of your *Owner's Manual* for more details.

FUEL TANK CAPACITY/ FUEL INFO

C-MAX Hybrid has a 13.5 gallon (51.1L) fuel tank capacity in addition to its high-voltage battery system. Use only **UNLEADED** fuel or **UNLEADED** fuel blended with a maximum of 15% ethanol. **Do not use ethanol (E85), diesel, fuel-methanol, leaded fuel or any other fuel because it could damage or impair the emission control system.**

ROADSIDE ASSISTANCE

Your new Ford vehicle comes with the assurance and support of 24-hour emergency roadside assistance. To receive roadside assistance in the United States, call **1-800-241-3673**. In Canada, call **1-800-665-2006**.

TOWING YOUR VEHICLE

Towing your vehicle behind another vehicle (such as an RV) may be limited. Refer to *Towing the Vehicle on Four Wheels* in the *Towing* chapter of the *Owner's Manual*.

TIRE PRESSURE MONITORING SYSTEM

Your vehicle illuminates a low tire pressure warning light  in your instrument cluster when one or more of your tires are significantly underinflated. If this happens, stop and check your tires as soon as possible. Inflate them to the proper pressure. Refer to the *Inflating Your Tires* section in the *Wheels and Tires* chapter of your *Owner's Manual* for more information.